

Work Order ID 101189

101189

Page 1

Monday, May 06, 2013 3:08:30 PM

Item ID: D350-689-011 Accept ***N9000040100*** Setup Start ***NS1***
 Revision ID: Stop ***NS2***
 Item Name: Dual High Back Seat
 Start Date: 5/3/2013 Start Qty: 1.00 ***1*** Cust Item ID:
 Required Date: 5/6/2013 Req'd Qty: 1.00 ***1*** Customer: CU-DAR001
 Reference: RMA RA111516

Approvals: Process Plan: MF Date: 13-5-6 Tooling: _____ Date: _____ Run Start ***NR1***
 QC: _____ Date: _____ SPC (Y/N): _____ Date: _____ Stop ***NR2***

| Sequence ID/ Work Center ID | Operation Description | Set Up/ Run Hours | Tool ID | Tool # | Plan Code | Accept Qty | Reject Qty | Reject Number | Insp. Stamp |
|--------------------------------|--------------------------|----------------------|---------|--------|--------------|---------------|---------------|------------------|----------------|
| Draw Nbr | Revision Nbr | | | | | | | | |
| DSI9588 | B | | | | | | | | |
| IIN-D350-689 | B | | | | | | | | |

100 0.00
100
 QC
 Quality Control
 Memo
 INSPECT RA 111516 D350-689-011 X.1 B#95812
 KIT IS COMPLETE
 NEEDS NEW PAPERWORK AND LABELS ONLY
 DAS 16 9-33 3/6/10/2

110 Identify as per dwg & Stock Location: Q20 0.00
110
 Packaging
 Packaging
 Memo
 0.00
 DAS 06 13/5/8

Work Order ID 101189***101189***

Page 2

Monday, May 06, 2013 3:08:30 PM

Item ID: D350-689-011

Accept

N900040100

Setup Start

NS1

Revision ID:

Stop

NS2

Item Name: Dual High Back Seat

Start Date: 5/3/2013 Start Qty: 1.00

1

Cust Item ID:

Required Date: 5/6/2013 Req'd Qty: 1.00

1

Customer: CU-DAR001

Reference: RMA RA111516

Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____

Run Start

NR1

QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Stop

NR2Sequence ID/
Work Center IDOperation
DescriptionSet Up/
Run Hours

Tool ID

Tool #

Plan
CodeAccept
QtyReject
QtyReject
NumberInsp.
Stamp

120

QC21- Final Inspection - Work Order Release

0.00

120

QC

Memo

0.00

Quality Control

ms 1305-08

RL 1305-8

Picklist Print

Monday, May 06, 2013 3:08:29 PM

Page 1

Work Order ID: 101189

Parent Item: D350-689-011

Parent Item Name: Dual High Back Seat

Start Date: 5/3/2013

Required Date: 5/6/2013

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP Rev:B03.05.09Reformat; Modify Step 1KJ/RF IPP Rev:C chg003 per DSI 9498 DD
10.02.11 verified by:JLM IPP REV:D 11.11.24 AS PER ECN11-674 DD VERF:EC

| Component Item ID/ Item Name | Replacement Item ID | Mfg/ Purch | Bin Item | Primary Location | Last Location | Route Seq ID | Unit of Measure | Qty on Hand | Qty per Kit | Total Qty | Qty Issued | Date Issued | Status |
|-------------------------------------|------------------------|---------------|-------------|---------------------|------------------|-----------------|--------------------|----------------|-------------|--------------|---------------|----------------|--------|
| D350-689-011 Dual High Back Seat | | Manufactured | No | | | | Each | 1.0000 | | 1 | | | |

Location

Loc Qty

Loc Code

FG

1

97648

1

1x 95812
mf
13-5-6

RA 111516 D350-689-011

B95812

Received @ Dart May 1st, 2013
Inspected @ Dart May 2nd, 2013

Customer: EUROTEC CANADA
Customer Contact: HOSS GOLANBARI
Shipped from: DUNDAS ON, CANADA

Instructions for RA 111516 D350-689-011 B95812 CHG006

- D350-689-011 B95812 is complete
 - D350-689-031 B96602 CHG001 is missing parts
 - AN4-4A M123900 qty x 1
 - AN4-10A M122407 qty x1
 - AN4-17A M124092 qty x1
 - AN970-4 M124101 qty x1
 - MS21042L4 M123900 qty x2
 - NAS1149F0432P M123900 qty x4
 - D350-689-013 B92864 CHG005 is complete
- All kits need new Batch #'s, new labels and new paper works
- All kits are at the current CHG #'s

Time Estimate = 3 HOURS

Departments Required: Stores & Quality Control

Pictures Attached = NO

QTY INSPECTED = x1 D350-689-011

**THIS INSTRUCTION SHEET MUST
BE ATTACHED TO THE
RESTOCKING WORK ORDER AT
ALL TIMES!!!!**